


ILLUSTRATED PARTS BREAKDOWN for TURBOTWIN ENGINE STARTERS MODELS: T109P/T115P

EFFECTIVE S/N: 9611-192



IMPORTANT NOTE

The purpose of this illustrated parts breakdown is to provide part number identification of the various components of the listed starters. Only those parts which may be disassembled at the field or repair shop level are broken out and identified. Certain parts or components are "factory only" assemblies, and should not be disassembled below the level shown in this document. Do not disassemble or reassemble the starter without referring to the proper TDI TURBOTWIN service manual. The use of improper procedures, non-authorized replacement parts or incorrect tools, may result in a faulty operating starter which could affect its performance or create a hazardous condition.

RI Mann & Associates Inc.

Engine Controls & Panels/Compressor Parts

860 North 9th Avenue, Brighton, CO 80603 Ph: (303) 659-5139 Fax: (303) 659-5309 www.rjmann.com



TOP ASSEMBLY PART NUMBERS COVERED IN THIS PUBLICATION

| MODEL NUMBER | PART NUMBER | PRESSURE RANGE (PSIG) | NO. OF NOZZLES (ITEM 19) | DIRECTION OF ROTATION | TDI DRIVE PART NUMBER |
|-----------------|---------------------|--------------------------|--------------------------------|-----------------------------|-----------------------------|
| T109P | T109-60013-P1R-1-30 | 60 - 150 | 9 | R.H. | 2-25482 |
| T115P | T115-60013-P1R-1-30 | 30 - 90 | 15 | R.H. | 2-25482 |

TURBOTWIN ENGINE STARTER REPAIR PARTS LIST MODELS: T109P / T115P

| KEY NO. | DESCRIPTION | PART NUMBER | |
|---------|-----------------------------------------|----------------|--|
| 4 | Screw | 19F- 25028-012 | |
| 5 | Washer | 9-93047 | |
| 6 | Rotor 2 | 2-26604 | |
| 7 | Woodruff Key | 9-90211-006 | |
| 8 | Seal Spacer (3) | 9-93083-001 | |
| 9 | Seal, Lip (2) | 2-26719 | |
| 10 | Bearing (2) | 9-91224 | |
| 11 | O-ring (2) | 9-90001-027 | |
| 12 | Wave Spring Washer | 9-90439 | |
| 13 | Nozzle 2/Containment Ring L.H. | 2-27333-00R | |
| 14 | O-ring 9-90001-050 | | |
| 15 | Rotor 1 | 2-26603 | |
| 16 | Woodruff Key | 9-90211-009 | |
| 17 | Lip Seal 2-22376 | | |
| 18 | Screw (14) 14F-19024-008 | | |
| 19i | Nozzle 1, R.H. (9 Nozzles) 2-26718-09R | | |
| 19ii | Nozzle 1, R.H. (15 Nozzles) 2-26718-15R | | |
| 20 | Pipe Plug 9-93556-004 | | |

TDI TURBOTWINTM FROM TECH DEVELOPMENT


| KEY NO. | DESCRIPTION | PART NUMBER |
|---------|------------------------------------------|-----------------------------|
| 21 | O-ring | 9-90001-034 |
| 22 | Screw (6) | 14F-31218-016 |
| 23 | Inlet Flange | 1-18967 |
| 24 | O-ring | 9-90001-037 |
| 25 | Set Screw (See Note 1) | 52F-50013-016 |
| 26 | Turbine Housing (See Note 1) | 2-27045 |
| 27 | Screw (6) | 14F-25020-016 |
| 28 | Pipe Plug | 9-93501-004 |
| 29 | Ring Gear (See Note 1) | 1-18780 |
| 30 | Bearing Spacer | 9-93091-001 |
| 32 | Clamping Plate | 2-26750 |
| 33 | Turbine Shaft | 2-27238 |
| 34 | Retainer Ring (3) | 9-92001-001 |
| 35 | Planet Gear Carrier Shaft 2P-20156-007 | |
| 36 | Washer (6) 9-93004 | |
| 37 | Planet Gear (3) (9:1 Gear Ratio) 1-18779 | |
| 38 | Needle Roller Bearing (3) 9-91004-001 | |
| 39 | Planet Shaft (3) 2P-20182 | |
| 40 | Woodruff Key (2) | 9-90211-019 |
| 41 | Bearing (2) 9-91351 | |
| 42 | Wave Spring Washer 9-90402-025 | |
| 43 | Bearing Spacer 9-93007 | |
| 46 | Retainer Plate 1-18817 | |
| 47 | Lockwasher | 9-93061-007 |
| 48 | Retainer Nut 9-92127-007 | |
| 51 | Retaining Ring | Included with item 50 or 57 |

$\begin{array}{c} \textbf{TDI } \textit{TURBO} \\ \textbf{TWIN} \\ \textbf{FROM TECH DEVELOPMENT} \end{array}$

| KEY NO. | DESCRIPTION | PART NUMBER | |
|---------|--------------------------------------------------|-----------------------------|--|
| 52 | Spring | Included with item 50 or 57 | |
| 53 | Set Screw | Included with item 50 or 57 | |
| 57 | Inertia Drive Assembly, R.H. | 2-25482 | |
| 58 | Gearbox Housing | 1-18810 | |
| 59 | Lock Nut (6) | 9-92107-015 | |
| 71 | Washer, Flat | 9-93018-011 | |
| 72 | Nut, Hex | 9-92108-003 | |
| 73 | Cover, Plate | 2-20192 | |
| 74 | Screw (6) | 11F-25020-072 | |
| 75 | Housing, Exhaust Cover | 2-27069 | |
| 76 | Spring, Compression | 9-90408-016 | |
| 77 | Post | 2-27223 | |
| 78 | Drive Housing (Shortened for CAT 3500 Series) | 2-25617 | |
| 79 | Screw (12) 11F-31218-024 | | |
| 80 | Needle Bearing | 9-91423 | |

Note 1: These parts are recommended factory only assembled.

TDI TURBOTWINTM FROM TECH DEVELOPMENT



Publication T1-717, Rev. 1 Issued April 15, 2006



FROM TECH DEVELOPMENT

ILLUSTRATED PARTS BREAKDOWN FOR T100-P TURBINE ASSEMBLY Effective S/N: 0109-181

| Key No. | Description | Part Number | |
|---------|--------------------------------|----------------|--|
| 1 | Screw (6) | 11F- 25020-072 | |
| 2 | Screen | 2-28175 | |
| 3 | Screw | 19F- 25028-012 | |
| 4 | Washer | 9-93047 | |
| 5 | Rotor 2 | 2-26604 | |
| 6 | Woodruff Key | 9-90211-006 | |
| 7 | Bearing Spacer | 9-93091-005 | |
| 8 | Bearing (2) | 9-91224 | |
| 9 | O-ring | 9-90001-027 | |
| 10 | Wave Spring Washer | 9-90439 | |
| 11 | Screw (4) | 11A-37516-008 | |
| 12i | Nozzle 2/Containment Ring R.H. | 2-27333-00R | |
| 12ii | Nozzle 2/Containment Ring L.H. | 2-27333-00L | |
| 13 | O-ring | 9-90001-050 | |
| 14 | Seal Spacer (2) | 9-93083-001 | |
| 15 | Lip Seal (2) | 2-26719 | |
| 16 | Rotor 1 | 2-26603 | |
| 17 | Woodruff Key | 9-90211-009 | |
| 18 | Screw (8) | 14F-19024-008 | |
| 19 | Nozzle 1, R.H. 9 Noz | 2-26718-09R | |
| 19 | Nozzle 1, R.H. 15 Noz | 2-26718-015R | |
| 20 | Pipe Plug | 9-93556-004 | |
| 21 | O-ring | 9-90001-034 | |
| 22 | Screw (6) | 14F-31218-016 | |



| Key No. | Description | Part Number |
|---------|-----------------|-------------|
| 23 | Inlet Flange | 1-18967 |
| 24 | O-ring | 9-90001-037 |
| 25 | Turbine Housing | 2-27869 |
| 26 | Pipe Plug | 9-93501-004 |
| 27 | O-ring (2) | 9-90001-050 |
| 28 | Ring Gear | 2-27870 |
| 29 | Bearing Spacer | 9-93091-001 |
| 30 | Clamping Plate | 2-26750 |
| 31 | Turbine Shaft | 2-26554 |

Note 2: The T100-P gearbox and drive assemblies have not been modified.

| Model | Overhaul Kit for S/N's before: 9611-191 | Overhaul Kit for S/N's: 9611- 192 to 0109-180 | Overhaul Kit for S/N's: 0109-181 and after |
|-------|-----------------------------------------|-----------------------------------------------|-----------------------------------------------|
| Р | T10P-27620 | T10P-27636 | T10P-28745 |




Figure 5. T100 Series Air Starter Turbine Assembly (S/N: 0109-181 and after)